

Date: <u>i/-6-24</u> Rego: <u>YMN-32M</u> Plant ID: <u>950</u>

Make	Terex	Model	AC250	
Service Type	500hr	Serial No:	82413	
Service Hrs.	11,500hr	KM		
Next Service	11,750hr	Due (+/- 50Hr. Reading)		

Status type: Satisfactory ✓ Action Required ★ Not Applicable NA

Status type: Satisfactory ✓ Action Required ×		Not Applicable NA		
Description		Status	Action/ Comments	
		250hr /	750hr Ser	vice
		C	ARRIER	
Check Hy	draulic Pump PTO, Mou	unting & Bolts		
	draulic Tank Oil Level		×	Tank cracked + leaking oil
	Air Leaks ALL Points		/	
Check for	Fuel Leaks ALL Points			
Check for	oil leaks ALL points		/	Hydraulic leak at tank
Check Tra	insmission/ retarder oil	level		
Check Tra	insfer Case Oil Level		/	
Check Tra	insfer Case Cooler Syst	em for Leaks	1,	
Check ALI	Differentials Oil Levels	3		
Check Pla	netary Reduction (s) Oi	Level		
Check Sus	sp Cylinder - Condition	Leaks / Positions		
Lubricate	suspension cylinder pive	ots		EP2 grease
Check cha	ssis frame and compor	ents for cracks or	/	
defects				
Check ALL	Suspension componer	nts - wear / tightness		
Check ALL	steering components -	wear/ tightness/ hoses		
Check ALL	Drive / Jack Shaft Univ	versal Joints		
Check / Lu	be ALL Universal Joints	s on Drive Line		
Check Bra	ke Pads/ linings wear &	Record thickness		
	L/H	R/H		Minimum Thickness = 2 mm
Axle 1				
Axle 2				
Axle 3			/	
Axle 4				
Axle 5				
Check Park Brake Operation		/		
Check Service Brake Operation		1		
Check Brake Expanding Cylinders		//		
Check Low Air Warning Devices				
Check all covers, panels for security		1		
Check Diff	Lock Operation			



D : All A: Tools of Webs / Coding ode		_
Drain ALL Air Tanks of Water / Sediments	-	
Inspect steering hoses	1	- FD0.0
Lube ALL axles, and steering knuckle bearing	1	EP2 Grease
Top up auto greaser (if fitted)	1	EP2 Grease
Check outrigger pads, rails and retainers for condition	1	
Inspect outrigger length cables and sensors	1/	
Lubricate outrigger beams	//	Lagermeister paste
Check Battery Electrolyte Level	-/-	
Visual Inspect Air Intake pipes & hoses	1	
Check Coolant & Inhibitor Level / Concentration	//	
Check ALL Coolant / Heater System Hoses	- /	
Visual Inspect Radiator Screen & Cooler Cores for		
Blockage		
Check Fan Operation	-	
Check Alternator & A/C Compressor Mount/Bolts	1	
Check Engine Drive Belts	1	
Check Engine, Lines & Hoses for Abrasion & Position	//	
Check Engine Piping for Leaks	1	
Visual Inspect Engine Mount(s) Condition	//	
Refill Windscreen Washer Water & Test Operation	//	
Check Horn(s)	/	
Check Wiper Operation	1	
Check Wheel nut tension		
Check Tyre Pressures & Tyre Condition	X	Type pressures were low
Check Seat Belt Condition / Operation	/	/
Check ALL Work Lights	1/	
Check ALL Instruments for Operation/Illumination	/	
Check clearance lights		
Check Head Lights HI/LO		
Check Stop Lights		
Check Reverse Light(s) & Alarm		
Check Indicators & Audible Warning		
Check ALL Warning Lights and Buzzers	//	
Spray all chrome rods with protectant		Decrodyn spray
Service trailer coupling and check air/electrical	- 14	If fitted
connections	MA	ii iitted
Inspect dolly for any defects	NA	If fitted
SUPE	RSTRUCT	URE
Lube Slew Gear / Bearing	1	EP2 Grease
Lubricate slew gear open teeth	1	Ceplattyn spray
Check slew gearbox oil level		LSX90
Lubricate slew gearbox pinion bearing		EP2 Grease
Visually Check Slew Bolts / Gear connections	1	
Check Winch Gearbox Oil Level	1	
Lubricate (grease) winch drum bearing		EP2 Grease
Lubricate Hook block	1	
Lubricate main boom sliding surfaces	NA	Bechem Berlub Grease
Check for correct operation of LPU and lube	1	



Spray all chrome cylinder rods		Decrodyn Spray
Top up auto greaser (if fitted)	/	EP2 Grease
Lubricate Luff Cyl. Bushes	/	EP2 Grease
Lubricate Rear Boom Pivot Bearings	/	EP2 Grease
Inspect Main Boom Track Rollers	1	2.2010800
Inspect Main Boom extension rope track rollers	/	
Visual check for cracks as per visual inspections list	1	
Check counterweight operation/ cylinder position sensors		
Check Winch Rope Condition & Lubrication		
Check Winch Unit Mountings & Bolts	1	
Visual Inspection of ALL Boom Sect. Damage	1	
Inspect ALL Sheaves on Boom Assy.	1	
Check sheave roller bearings		
Check Hoist Limit Switch Operation		
Check ALL Hydraulics for Correct Operation	1	
Check ALL Hydraulic Cyl's for Damage/Leaks	1	
Check ALL Hydraulic Hoses for Damage/Leaks	-	
Check ALL Wiring for Damage & Correct Routing	-	
Check Fan Operation	-	
Check Clearance Lights	-	
Check ALL Work Lights	-	
Check all override key switches return to neutral position	1	
Check ALL Instruments for Operation/Illumination	-	
Check Horn(s)	-	
Check Wiper Operation	-/-	
Check ALL Warning Lights and Buzzers		
Check Rotating Light Operation	//	
Check Interior Light Operation	-	·
Check AM/FM Radio Operation	-/-	
Check Cabin for Water Leaks	1	
	/	
Check Seat Mounting & Operation	/	
Refill Windscreen Washer Water & Test Operation	/	Upper and Lower
Check Heater Operation	X	Top cab not working - faulty cont.
Check Air Conditioning	/_	6
Check all crane functions for correct operation	/	
Lift Test Weight if Available	/	
Check LMI / SLI Operation / Calibration	1,	
Anti-two block operational	/	
Boom length & angle indicators	/,	
Manual boom length & angle indicators	/	
Level indicators	1,	
Emergency controls (E-Stops)	/_	
Operation & safety manuals	/,	
2 way radios condition / operation		
500h	nr Service	
Carry Out 250 / 750 Hour Service Schedule	/	
Add the Following:		



Replace engine oil and filters		Castrol Vecton E7	
Replace reduction hub oil	/	EP85W/140 gear oil	
Replace hydraulic return filters	X		
Replace hydraulic breather filters	×		
Replace air filters		If necessary	
Lubricate cab tilt cylinder pivots		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
Lubricate slew lock pin	/		
Lubricate guide rail of sliding door			

OTHER NOTES:
* Hydraulic tank cracked + leaking
* Heater top cab not working due to faulty heater
* Tyre pressures were low and need rotating.
on rims - 3rd oxle RHS has screw in it and
has been marked for tyre shop

Completed by:	Christian. C	Mechanic / Fitter	11-6-24
	Name	Position	Date
	Cheldre U		11-6-24
	Name	Position	Date